

## LUSTRE DESKTOP LIGHT

Model LUSTRE-SLV  
Model LUSTRE-WHT

LUSTRE Rev A 4/17








## SET-UP AND OPERATION

## LUSTRE

**PLEASE REVIEW** these instructions before beginning the installation. Check that all parts needed were provided with your order. Contact your supplier if any parts are missing. Do not discard the packaging until satisfied that the product operates to your satisfaction.

### PARTS PROVIDED


<p>Lamp Body (1)</p> 	<p>Lamp Base (1)</p> 	<p>Power Supply (1)</p> 	<p>Splitter (1)</p>  <p>Cord Clips (5)</p> 
--	--	---	--

### Set-Up

1. Plug the lamp body into the lamp base. Push down until the lamp body “clicks” in place.
2. Connect the lamp cable and base cable to the two-cord side of the splitter.
3. Connect the single cord coming from the splitter to the power supply.  
**IMPORTANT:** For proper operation, the jacks on the splitter and power supply must be securely inserted into their respective connectors.
4. Plug the power supply into a standard 115V AC wall outlet.

### Operation

5. Tap the power button to turn the lamp on and off. Press and hold to cycle through the four different brightness settings.  
**NOTE:** When the lamp is off, turning the lamp on will return it to its previous power setting
6. Rotate, telescope, and angle the lamp to direct the light as desired. See illustration.
7. The occupancy sensor shuts off the lamp when no motion is detected for more than 15 minutes. It returns the lamp to its original setting when motion is detected.
8. *Optional:* Use the USB port on the lamp base to recharge phones, tablets, and other devices.
9. *Optional:* Use the cord clip to help organize and manage the cables.



## Specifications

- Power consumption: 6W
- Lumens (maximum): 350
- Color temperature: 3500K
- CRI: 83
- Lamp life: 50,000 hours
- USB port output: 12VDC, 2.0A



800.833.3746 | [esiergo.com](http://esiergo.com)