


# TITAN2-EDGE: Disassembly Instructions



TITAN2-EDGE Assembled

APPLIES TO: TITAN-EDGE






## TITAN2-EDGE: Monitor Disassembly



#### TITAN2-EDGE Components for breakdown






## TITAN2-EDGE: Keyboard Disassembly



#### TITAN2-EDGE Components for breakdown



### **Material Identification**

A: Keyboard Platform

- Phenolic

B: VESA Mount Knuckle

- Phenolic

C: Long Limb

- Steel

D: Short Limb

- Steel 3

E: Slider

- Steel

**Recommended Tools** 





Goggles








13mm Ratchet 6mm Allen Wrench



# DISASSEMBLY

# TITAN2-EDGE: CPU Holder Disassembly

#### TITAN2-EDGE Components for breakdown



### Material Identification

A: Non Skid Pads

- Foam

B: J Bracket 1

- Steel 📫

C: J Bracket 2

- Steel 📫

D: Sleeve

- Steel 🐔

E: Washer

- Plastic

F: Knob

- Steel

**Recommended Tools** 



Gloves



Goggles



½" Wrench










## TITAN2-EDGE: Track Disassembly



#### TITAN2-EDGE Components for breakdown



## **Material Identification**

A: Socket Head Screw

- Steel 🛟

B: J Bracket

- Steel 🛟

C: Bolt

- Steel 🛟

D: Wall Track 1

- Steel 🚯

E: Wall Track Cover 1

- Plastic

F: Wall Track Cover 2

- Plastic

G: Keyboard Slider

- Steel 🛟

H: Wall Track 2

- Steel 🛟

I: Monitor Arm Slider

- Steel 🛟



**Recommended Tools** 



Gloves





Goggles

Flathead Screwdriver